


innuos

NAZARÉFLOW

DIGITAL AUDIO RECLOCKER



Quick Start Guide

Thank you for buying our **NazaréFLOW** and welcome to the Innuos family!

This **Quick Start Guide** will show you how to get started with your new device. For further details, troubleshooting and help with advanced setups, visit our Community Forum at **<https://community.innuos.com>**

For more information on how best to use the NazaréFLOW for optimal performance, please visit our Knowledge Base using this QR code:



You can also join us on social media to keep informed about events, new features and products here:



[instagram.com/innuos](https://www.instagram.com/innuos)



[x.com/innuos](https://twitter.com/innuos)




[youtube.com/innuos](https://www.youtube.com/innuos)



[facebook.com/innuos](https://www.facebook.com/innuos)


Enjoy the music
-The Innuos Team

Box Contents



- 1. Innuos **NazaréFLOW**
- 2. 1.75m Mains Power Cable
- 3. Spare 2A 'Slow-blow' Fuse x 2
- 4. 2m USB Cable

NazaréFLOW Rear Panel Diagram



1. Output Module Bay

2. Reclocked USB DAC Output

3. PreciseUSB Input


From Nazaré PreciseUSB port or other USB source

4. Chassis Ground Port


5. AC Inlet

6. On/Off Rocker Switch

Connect your NazaréFLOW to Source




Connect your NazaréFLOW to a DAC




Note: If using a DAC Connection Module within the FLOW (ProISL, CH-Link etc) then use their respective cable instead of USB.

Connect your system to mains power



Turning the NazaréFLOW ON/OFF



innuos